

Dektite Combo

Flash over or around, a standard Dektite and Retrofit all in one

- ✓ The unique cone design makes the combo range suitable for both standard and retrofit applications.
- ✓ When retrofit is required just cut and apply clips for ease of application. **Clips included.**
- ✓ Provides 10 - 20mm continuous contact with flashed pipe providing a watertight seal.
- ✓ Clear markings makes for easier cutting to pipe size.
- ✓ Size ranges - Numbers 1 - 10 (5 - 750mm)
- ✓ Available in black EPDM.
- ✓ Just fit it and forget it - we've got you covered.
- ✓ EPDM withstands temperatures from -50°C to 115°C and up to 150°C intermittently.



Combo Selection Guide

CODE	DESCRIPTION	PIPE (MM)	BASE (MM)	ROOF PITCH
DC101BC	Dektite Combo #1	5-60	139 x 139	10-40°
DC102BC	Dektite Combo #2	45-85	177 x 177	10-40°
DC103BC	Dektite Combo #3	5-127	221 x 221	10-40°
DC104BC	Dektite Combo #4	75-175	285 x 285	10-40°
DC105BC	Dektite Combo #5	108-190	366 x 366	10-40°
DC106BC	Dektite Combo #6	125-230	366 x 366	10-40°
DC107BC	Dektite Combo #7	150-280	454 x 454	10-40°
DC108BC	Dektite Combo #8	175-330	454 x 454	10-40°
DC109BC	Dektite Combo #9	240-508	705 x 705	10-40°
DC110BC	Dektite Combo #10	400-750	965 X 965	10-40°

Combo Square Selection Guide

CODE	DESCRIPTION	PIPE (MM)	BASE (MM)	ROOF PITCH
DCS103BC	Dektite Combo Square	20-125	221 x 221	10-40°

Dektite Combo

Flash over or around, a standard Dektite and Retrofit all in one

Installation Instructions

Standard Application

- 1 Trim the cone to suit pipe size using sharp tin snips.
- 2 Slide down pipe using water as a lubricant.
- 3 Apply a liberal bead of silicone sealant on underside of flexible aluminium base.
- 4 Press base to the roof profile by hand. Smooth out any awkward creases. Don't fully extend to allow for vibration.
- 5 Fasten using self drilling washered screws or sealed rivets.

Retrofit Application

- 1 Trim cone to suit pipe size then cut seam and aluminium base using sharp tin snips.
- 2 Apply a liberal bead of neutral cure 100% silicone sealant (roof and gutter approved) to one side of the cut seam.
- 3 With seam in downstream position wrap cone around pipe and engage 1st double clip at top of seam using multigrips.
- 4 Engage remaining clips working down from top of cone to base making sure that you do not over crimp.
- 5 Apply liberal bead of neutral cure 100% silicone sealant (roof and gutter approved) to underside of Dektite Combo and shape to roof by hand. Screw down using self drilling washered screws or sealed rivets.
- 6 Fasten flashing down by placing a fastener either side of seam first then secure rest of base working outwards in opposing pairs.
- 7 Apply sealant to top of base closure and any other potential leak areas.