

Dektite Combo

Flash over or around, a standard Dektite and Retrofit all in one

Installation Instructions

Standard Application

- 1 Trim the cone to suit pipe size using sharp tin snips.
- 2 Slide down pipe using water as a lubricant.
- 3 Apply a liberal bead of silicone sealant on underside of flexible aluminium base.
- 4 Press base to the roof profile by hand. Smooth out any awkward creases. Don't fully extend to allow for vibration.
- 5 Fasten using self drilling washered screws or sealed rivets.

Retrofit Application

- 1 Trim cone to suit pipe size then cut seam and aluminium base using sharp tin snips.
- 2 Apply a liberal bead of neutral cure 100% silicone sealant (roof and gutter approved) to one side of the cut seam.
- 3 With seam in downstream position wrap cone around pipe and engage 1st double clip at top of seam using multigrips.
- 4 Engage remaining clips working down from top of cone to base making sure that you do not over crimp.
- 5 Apply liberal bead of neutral cure 100% silicone sealant (roof and gutter approved) to underside of Dektite Combo and shape to roof by hand. Screw down using self drilling washered screws or sealed rivets.
- 6 Fasten flashing down by placing a fastener either side of seam first then secure rest of base working outwards in opposing pairs.
- 7 Apply sealant to top of base closure and any other potential leak areas.

Dektite Flatseal

For flat and low pitch roofs

- ✓ For flat and low pitch roofs with single ply or bitumen coverings.
- ✓ No special tools or fittings are needed.
- ✓ Flatseal EPDM snaps tight to pipe without clips.
- ✓ Seals to roof with hot or cold liquid bitumen.
- ✓ Black EPDM for maximum UV and ozone resistance.



CODE	BASE (MM)	PIPE (MM)	COLOUR
FS25-175	345	25-175	BLACK (EPDM)

