

Dektite Combo

Flash over or around. A standard Dektite and Retrofit all in one.

Installation Instructions

Standard Application

- 1 Trim the cone to suit pipe size using sharp tin snips.
- 2 Slide down pipe using water as a lubricant.
- 3 Apply a liberal bead of silicone sealant on underside of flexible aluminium base (refer to page 13 for silicone types).
- 4 Press base to the roof profile by hand. Smooth out any awkward creases. Don't fully extend to allow for vibration.
- 5 Fasten using self drilling washered screws or sealed rivets.

Retrofit Application

- 1 Trim cone to suit pipe size then cut seam and aluminium base using sharp tin snips.
- 2 Apply a liberal bead of silicone to one side of the cut seam.
- 3 With seam in downstream position wrap cone around pipe and engage 1st double clip at top of seam using multigrips.
- 4 Engage remaining clips working down from top of cone to base making sure that you do not over crimp.
- 5 Apply liberal bead of silicone sealant to underside of Dektite Combo and shape to roof by hand (refer to page 15 for silicone types). Screw down using self drilling washered screws or sealed rivets
- 6 Fasten flashing down by placing a fastener either side of seam first then secure rest of base working outwards in opposing pairs.
- 7 Apply sealant to top of base closure and any other potential leak areas.

Dektite Flatseal

For flat and low pitch roofs

- ✓ For Flat and low pitch roofs with single ply or bitumen coverings.
- ✓ No special tools or fittings are needed.
- ✓ Flatseal EPDM snaps tight to pipe without clips.
- ✓ Seals to roof with hot or cold liquid bitumen.
- ✓ Black EPDM for maximum UV and Ozone resistance.



Code	Base (mm)	Pipe (mm)	Colour
FS25-175	345	25-175	BLACK (EPDM)

